




Parts List : 101853

2014.01

No.	Parts No.	Description	Q'ty
1	012001	Screw	1
2	012002	O-Ring	1
3	012003	O-Ring	2
4	012004	Air Regulator	1
5	012005	Spring	1
6	012006	Valve Stem Bushing	1
7	012007	Valve Stem	1
8	012008	O-Ring	1
9	012009	Air Inlet	1
10	012010	Exhaust Sleeve	1
11	012011	O-Ring	1
12	012012	Cone Muffler	1
13	012013	Spring Pin	1
14	012614	Lever	1
15	012015	Protecting Rubber	1
16	012016	Housing	1
17	012017	Bearing	1
18	012018	Rear Plate	1
19	012019	Rotor Blade	4
20	014220	Rotor	1
21	012021	Cylinder	1
22	012022	Pin	2
23	012623	Front Plate	1
24	012624	Bearing	1

No.	Parts No.	Description	Q'ty
25	012625	Washer	1
26	014227	Thread Ring Gear	1
27	011827	Bearing	2
28	014228	Idler Gear	3
29	012629	Needle Bearing	3
30	012630	Idler Gear Pin	3
31	011831	Gear Plate	1
32	011832	Washer	1
33	011833	Clamp Nut	1
34	011834	Bearing Bushing	1
35	011835	Bearing	2
36	011836	Bevel Gear	1
37	011837	Angle Housing	1
38	018930	Oil Plug	1
39	011839	Bearing	1
40	011840	Ball Bearing	1
41	011841	Shaft	1
42	011842	Key	1
43	011843	Bevel Gear	1
44	011844	Bearing Bushing	1
45	011845	Retainer Ring	1
46	012634	Washer	1
47	011847	3/8" Chuck & Key	1