



Parts List : 11505A

2014.01

No.	Parts No.	Description	Q'ty
1	012001	Screw	1
2	012002	O-Ring	1
3	012003	O-Ring	2
4	012004	Air Regulator	1
5	012005	Spring	1
6	012006	Valve Stem Bushing	1
7	012007	Valve Stem	1
8	012008	O-Ring	1
9	012009	Air Inlet	1
10	012010	Exhaust Sleeve	1
11	012011	O-Ring	1
12	012012	Cone Muffler	1
13	012013	Spring Pin	1
14	012014	Lever	1
15	012015	Protecting Rubber	1
16	012016	Housing	1
17	012017	Bearing	1
18	012018	Rear Plate	1
19	012019	Rotor Blade	4
20	012020	Rotor	1
21	012021	Cylinder	1
22	012022	Pin	2
23	012023	Bearing Spacer	1

No.	Parts No.	Description	Q'ty
24	012024	Front Plate	1
25	018925	Bearing	3
26	011526	Bevel Gear	1
27	018927	Nut	1
28	018928	Clamp Nut	1
29	018929	Angle Housing	1
30	018930	Oil Plug	1
31	018931	Snap Ring	1
32	011532	Bevel Gear	1
33	018933	Bearing	1
34	011534	Shaft	1
35	018935	Key	1
36	018936	Clamp Nut	1
37	011537	Disc Cover	1
38	011538	Screw	1
39	011539	Nut	1
40	011540	2" Disc Wheel	1
41	011541	Washer	1
42	011542	Disc screw	1
43	012031	Spanner 14mm	1
44	014253	Hex Key (5mm)	1
45	011545	Hex Key (3mm)	1