



## Parts List : 118152, 118156

2014.01

No.	Parts No.	Description	Q'ty
1	012001	Screw	1
2	012002	O-Ring	1
3	012003	O-Ring	2
4	012004	Air Regulator	1
5	012005	Spring	1
6	012006	Valve Stem Bushing	1
7	012007	Valve Stem	1
8	012008	O-Ring	1
9	012009	Air Inlet	1
10	012010	Exhaust Sleeve	1
11	012011	O-Ring	1
12	012012	Cone Muffler	1
13	012013	Spring Pin	1
14	012014	Lever	1
15	012015	Protecting Rubber	1
16	012016	Housing	1
17	012017	Bearing	1
18	012018	Rear Plate	1
19	012019	Rotor Blade	4
20	012020	Rotor	1
21	012021	Cylinder	1

No.	Parts No.	Description	Q'ty
22	012022	Pin	2
23	012023	Bearing Spacer	1
24	012024	Front Plate	1
25	012025	Bearing	2
26	018126	Bevel Gear	1
27	018927	Nut	1
28	018928	Clamp Nut	1
29	018129	Angle Housing	1
30	018930	Oil Plug	1
31	018931	Snap Ring	1
32	018132	Bevel gear	1
33	018133	Bearing	2
34	018134	Shaft	1
35	018935	Key	1
36	018136	Clamp Nut	1
37A	012029A	Collet 1/4" (for 118152)	1
37B	012029B	Collet 6mm (for 118156)	1
38	012030	Collet Nut	1
39	012031	Spanner 14mm	1
40	012032	Spanner 19mm	1