



Parts List : 120032, 120036

2014.01

No.	Parts No.	Description	Q'ty
1	015001	Screw	1
2	012002	O-Ring	1
3	012003	O-Ring	2
4	015004	Air Regulator	1
5	012005	Spring	1
6	012006	Valve Stem Bushing	1
7	015007	Valve Stem	1
8	012008	O-Ring	1
9	012009	Air Inlet	1
10	015010	Exhaust Sleeve	1
11	015011	O-Ring	1
12	015012	Cone Muffler	1
13	012013	Spring Pin	1
14	012014	Lever	1
15	015015	Protecting Rubber	1
16	015016	Housing	1
17	020017	Bearing	2
18	015018	Rear Plate	1
19	015019	Rotor Blade	4
20	015020	Rotor	1

No.	Parts No.	Description	Q'ty
21	015021	Cylinder	1
22	015022	Pin	2
23	012023	Bearing Spacer	1
24	015024	Front Plate	1
25	018925	Bearing	3
26	020026	Bevel Gear	1
27	018927	Nut	1
28	020028	Clamp Nut	1
29	020029	Angle Housing	1
30	018930	Oil Plug	1
31	020031	Snap Ring	1
32	020032	Bevel Gear	1
33	020033	Shaft	1
34	018935	Key	1
35	020035	Clamp Nut	1
36A	012029A	Collet 1/4" (for 120032)	1
36B	012029B	Collet 6mm (for 120036)	1
37	012030	Collet Nut	1
38	012031	Spanner 14mm	1
39	012032	Spanner 19mm	1