



Parts List : 213000

2016.01

No.	Parts No.	Description	Q'ty
1	021101	Air Inlet	1
2	021102	Pin	1
3	021103	Steel Ball	2
4	021104	Spring	1
5	021105	Spring Pin	1
6	021106	O-Ring	1
7	021107	Air Regulator	1
8	021108	Safety Throttle	1
9	021309	Snap Ring	1
10	021310	O-Ring	3
11	021311	Bushing	1
12	021112	Spring Ping	1
13	021113	Pin	1
14	021114	Piston	1
15	021115	O-Ring	1
16	021116	Spring	1
17	021117	O-Ring	1
18	021118	Reverse Valve	1
19	021319	Housing	1
20	035118	Bearing	1
21	021321	Rear Plate	1
22	021122	Spring Pin	1
23	021323	Rotor	1
24	021324	Rotor Blade	5

No.	Parts No.	Description	Q'ty
25	021325	Cylinder	1
26	021326	Front Plate	1
27	021127	Spring Pin	2
28	035125	Bearing	1
29	021329	Top Adjuster	1
30	021130	Washer	1
31	021331	Hammer Seat	1
32	021332	Hammer	2
33	021333	Pin	2
34	021334	Cam	1
35	021335	Anvil	1
36	021336	Bushing	1
37	021337	Washer	1
38	021338	Snap Ring	1
39	021138	Washer	2
40	021139	Spring	1
41	021140	Ball Retainer	1
42	021141	Snap Ring	1
43	021343	Bushing	1
44	021344	Front Housing	1
45	021345	O-Ring	2
46	021346	Muffler	1
47	021145	Hook	1