



Parts List : 300300G

2012.02

No.	Parts No.	Description	Q'ty
1	030301	Motor Housing	1
2	030302	Rear Cap	1
3	030303	Rear Cap Gasket	1
4	030304	Cap Screw	4
5	030305	Anvil Bushing	1
6	030306	Oil Seal	1
7	030307	Muffle Cover	1
8	030308	Screw	1
9	030309	Aluminum Plug	1
10	030310	Oil Plug	1
11	030311	Trigger	1
12	030312	Trigger Pin	1
13	030313	Spring Pin	1
14	030314	Screw	1
15	030315	Throttle Valve Stem	1
16	030316	Throttle Valve Bushing	1
17	030317	Steel Ball	1
18	030318	Throttle Valve Spring	1
19	030319	Hose Fitting (NPT-18T)	1
19-1	030319-1	Hose Fitting (NPT-19T)	1
20	030320	Dust Cover	1
21	030321	Valve Sleeve	1
22	030322	Reverse Valve	1
23	030323	Air Regulator	1
24	030324	O-Ring	1

No.	Parts No.	Description	Q'ty
25	030325	Ring	1
26	030326	Pin	1
27	030327	Spring	1
30	030330	Front Rotor Bearing	1
31	030331	Oil Seal	1
32	030332	Front End Plate	1
33	030333	O-Ring	1
34	030334	Cylinder Pin	1
35	030335	Cylinder	1
36	030336	Rotor	1
37	030337	Rotor Blade	6
38	030338	Rear End Plate	1
39	030339	Rear Rotor Bearing	1
40	030340	Hammer Cage	1
41	030341	Drive Cam Foundation	1
42	030342	Steel Ball	1
43	030343	Drive Cam	1
44	030344	Hammer Pin	2
45	030345	Spring	1
46	030346	Standard Anvil	1
47	030347	Anvil Washer	1
48	030348	O-Ring	1
49	030349	Socket Retainer	1
50	030350	O-Ring	2