



Parts List : 400511

2015.08

No.	Parts No.	Description	Q'ty
1	040501	Cap Screw	8
2	040502	Hammer Case	1
3	040503	Anvil Bushing	1
4	040504	O-Ring	1
5	040505	Socket Retainer	1
6	040506	O-Ring	1
7	040507	Standard Anvil	1
8	040508	Hammer Pin	2
9	040509	Hammer Frame	1
10	040510	Hammer	1
11	040511	Motor Housing	1
12	040512	Trigger	1
13	040513	Throttle Valve Bushing	1
14	040514	Throttle Valve Stem	1
15	040515	Throttle Valve Spring	1
16	040516	Exhaust Deflector	1

No.	Parts No.	Description	Q'ty
17	040517	Hose Fitting	1
18	040518	Rotor Bearing	2
19	040519	Front End Plate	1
20	040520	Cylinder	1
21	040521	Cylinder Pin	1
22	040522	Rotor	1
23	040523	Rotor Blade	6
24	040524	Rear End Plate	1
25	040525	Rear Cap Gasket	1
26	040526	Rear Cap	1
27	040527	O-Ring	1
28	040528	Reverse Valve	1
29	040529	Spring	1
30	040530	Steel Ball	1
31	040531	Reverse Valve Retainer	1