



Parts List : 4K0950, 4K0952

2013.05

No.	Parts No.	Description	Q'ty
1	04K501	Motor Housing	1
2	04K502	O-Ring	1
3	04K503	O-Ring	2
4	04K504	Guide Tube	1
5	04K505	Retainer	1
6	04K506	O-Ring	1
7	04K507	Throttle Valve Seat	1
★ 8	04K508	Throttle Valve Assembly {incl. 8A,8B,8C}	1 Set
● 8A	04K508A	Throttle Valve Pin	1
● 8B	04K508B	Rubber Seal	1
● 8C	04K508C	Throttle Valve	1
9	04K509	Spring	1
10	04K510	Exhaust Deflector	1
11	04K511	O-Ring	1
12	04K512	Hose Fitting	1
13	04K513	Spring Pin	1
14	04K514	Spring Pin	1
15	04K515	Screw	4
★ 16	04K516	Trigger Assembly {incl. 17,18}	1 Set
● 17	04K517	O-Ring	1
● 18	04K518	Trigger Pin	1
19	04K519	Spring Pin	1
20	04K520	Steel Ball	1
21	04K521	Spring	1
22	04K522	Reverse Valve	1

No.	Parts No.	Description	Q'ty
23	04K523	O-Ring	1
24	04K524	O-Ring	1
25	04K525	E-Ring	1
26	04K526	Rear Rotor Bearing	1
27	04K527	Rear End Plate	1
28	04K528	Rotor Blade	6
29	04K529	Rotor	1
30	04K530	Spring Pin	2
31	04K531	Cylinder	1
32	04K532	Front End Plate	1
33	04K533	Front Rotor Bearing	1
34	04K534	Washer	1
35	04K535	Hammer	2
36	04K536	Hammer Frame	1
37	04K537	Hammer Pin	2
38A	04K538A	Standard Anvil (for 4K0950)	1
38B	04K538B	2" Extended Anvil (for 4K0952)	1
39	04K539	O-Ring	1
40	04K540	Socket Retainer	1
41	04K541	Hammer Case Gasket	1
● 42	04K542	Anvil Bushing	1
★ 43	04K543	Hammer Case Assembly {incl. 42,44}	1 Set
● 44	04K544	Grease Fitting	1
45	04K545	Muffler Element	1
TK	04K5TK	Tune-Up Kit (3(2),6,9,11,17,20,21, 23,24,26,28(6),33,39,40,41,45)	1 Set

★ Must be Purchased in Assembly Set

● Cannot be Sold Separately due to Assembly Difficulty