



Parts List : 801200, 801206

2012.02

No.	Parts No.	Description	Q'ty
1	081201	Cap Screw	8
2	081202	Hammer Case	1
3	081203	Anvil Bushing	1
4	081204	O-Ring	1
5	081205	Socket Retainer	1
6	081206	O-Ring	1
7	081207A	Standard Anvil (for 801200)	1
	081207B	6" Extended Anvil (for 801206)	1
	081207C	Anvil Snap Ring	1
8	081208	Hammer Pin	2
9	081209	Hammer Frame	1
10	081210	Hammer	2
11	081211	Hammer Frame Rear Washer	1
12	081212	Motor Housing	1
13	081213	Trigger	1
14	081214	Trigger Retainer	1
15	081215	Screw	1
16	081216	Washer	1
17	081217	Throttle Valve Bushing	1
18	081218	Throttle Valve Stem	1

No.	Parts No.	Description	Q'ty
19	081219	Throttle Valve Spring	1
20	081220	Exhaust Deflector	1
21	081221	Hose Fitting	1
22	081222	Front Rotor Bearing	1
23	081223	Front End Plate	1
24	081224	Cylinder Pin (4 x 10)	1
25	081225	Cylinder	1
26	081226	Cylinder Pin (4 x 22)	1
27	081227	Rotor	1
28	081228	Rotor Blade	6
29	081229	Rear End Plate	1
30	081230	Rear Rotor Bearing	1
31	081231	Rear Cap Gasket	1
32	081232	Rear Cap	1
33	081233	O-Ring	1
34	081234	Reverse Valve	1
35	081235	Spring	1
36	081236	Steel Ball	1
37	081237	Reverse Valve Retainer	1